

SL Tutorial

Cleaning SLA resin from small cavities

- Using ultrasonic tank. Fill with cold water about 2 inches deep.
- Put SLA parts in beaker and 2 1/2 inches of Alcohol.
- Run ultrasonic tank for 5 minutes.
- Remove part and blow off with air.
- If resin is still in cavities rerun thru ultrasonic tank for another 5 minutes. (repeat until cavities are clear of liquid resin)

Note: If water is getting warm. Change water. Never run ultrasonic tank full of alcohol. (Fire hazard.)

By Bob Zubrickie

Disclaimer:

This is a suggestion only. The 3DSUG nor the submitter are liable for the actions or outcome of this suggestion.