

## SL Tutorial

### Removal of cured residual SLA resin from removable steel bracketry

Tools needed:

Bucket, tub, or sink

Warm water

Liquid soap

Sharp metal or plastic putty knife

- Put resin coated metal part in bucket, tub or sink
- Fill container with warm to hot water and a few drops of liquid soap
- Allow to soak over night
- Scrape off soft cured resin with putty knife

Allow soak longer if needed. Try to keep water warm to hot. (change water if needed)

By Bob Zubrickie

Disclaimer:

This is a suggestion only. The 3DSUG nor the submitter are liable for the actions or outcome of this suggestion.