

SL Tutorial

Removal of large SLA parts from platform

- Pour 1/4 inch of Alcohol in a pan. (Any type of alcohol will work)
- Place platform of parts or part in pan of alcohol
- Platform should be totally immersed in alcohol and the supports should be wicking up the alcohol but not touching bottom surface of part.
- Leave soak for approximately 1 hour. (This depends on the type of resin being run) Try various time durations.
- Once Supports are soft. Twist part off platform.
- Using a terrycloth rag wipe the remainder of supports from part.

Allow bottom surface to dry before post finishing. (Time may vary with type of resin)

By Bob Zubrickie

Disclaimer:

This is a suggestion only. The 3DSUG nor the submitter are liable for the actions or outcome of this suggestion.